

# Rubber Adapters

## RUBBER HUMP HOSES (A)

MODEL #	TOP"	BOTTOM"	LENGTH
RHH-250	2.5	2.5	5.25
RHH-300	3	3	5.25
RHH-400	4	4	5.25
RHH-500	5	5	6
RHH-600	6	6	6
RHH-700	7	7	6
RHH-800	8	8	6

## RUBBER HUMP HOSE REDUCERS (B)

MODEL #	TOP"	BOTTOM"	LENGTH
RHR-4030	3	5	5.25
RHR-5040	4	5	5.25
RHR-6050	5	6	6
RHR-7060	6	6	5
RHR-8060	6	7	6
RHR-8070	7	7	6

## RUBBER SIZING INSERTS (C)

MODEL #	ID"	OD"	LENGTH
RSI-4030	3	4	5.25
RSI-5040	4	5	5.5
RSI-5045	5	6	6
RSI-6050	6	7	5
RSI-6055	6	8	6
RSI-7060	4	5	5.5
RSI-7065	5	6	6
RSI-8070	6	7	5
RSI-8075	6	8	6
RSI-9080	6	7	5

## RUBBER 90° ELBOW (D)

MODEL #	TOP"	BOTTOM"	LENGTH
R90-300	3	3	3.25
R90-400	4	4	4.125
R90-500	5	5	4.125
R90-600	6	6	5
R90-700	7	7	5.56
R90-800	8	8	6.5

## RUBBER 45° ELBOW (E)

MODEL #	TOP"	BOTTOM"	LENGTH
R45-300	3	3	3.75
R45-400	4	4	4.25
R45-450	4.5	4.5	3.5
R45-500	5	5	4.5
R45-600	6	6	5
R45-700	7	7	5.56
R45-800	8	8	6.5

