FSB26-007 | 2026

CCAP PRESSURIZER: HVAC Access Door Panel

Installing the CCAP HVAC Access Door Panel on a Caterpillar machine is a straightforward 3-step process that takes 20–30 minutes. The panel uses the machine's existing HVAC housing hinge and bolts — no drilling or fabrication required.

(Included in the kit: HVAC Access Door Panel, adhesive gasket, hose clamp.)

The CCAP HVAC Access Door Panel mounts on the existing HVAC housing hinge and bolts — no drilling, no fabrication. The included adhesive gasket and hose clamp are all you need to complete the installation.

1. Install the door panel.

Remove the existing HVAC housing door. Hang the CCAP Access Door Panel on the same hinge and secure it using the pre-existing bolts.

2. Apply the gasket.

Peel the protective film from the adhesive-backed gasket. Press the gasket firmly onto the inside face of the door panel, positioned so that when the door is closed it seals completely around the air filter opening in the HVAC housing.

3. Connect the CCAP hose.

Close the door panel. Slide the CCAP pressurizer hose over the metal pipe port on the door panel and secure it with the included hose clamp.

Estimated installation time: 20–30 minutes

©2026 EcoProUSA.com | All rights reserved.

2443 W 12th Street, Suite 6, Tempe, AZ 85281 customerservice@ecoprousa.com (602) 820-5143