ECO PRO

DONE IN 90 MINUTES.

NO FABRICATION. NO HOSES. NO HEADACHES.

~90 MIN	SIDE MOUNT	NO HOSES	USA
install	flush fit	req'd	made

BRACKET DETAIL

CCAP + TURBO II HD INSTALLED — KOMATSU WA475

BOLTS RIGHT ON

No drilling, no fabrication, no custom work. Mounts flush to the cab panel with the hardware included.

HOSES? THERE AREN'T ANY.

The CCAP connects directly to the bracket. Nothing to route, nothing to clamp, nothing to leak later.

BUILT FOR THIS MACHINE

Designed specifically for the WA475-10 and WA485-10. Every hole lines up. Every time.

You've Got Better Things to Do Than Fight a Bracket.

This bracket was designed with the guy doing the install in mind. It mounts flush to the side of the cab, the CCAP drops right on, and you're done. No improvising, no extra trips to the shop, no re-doing it next week.

WHAT MAKES THIS INSTALL EASY:

- **Hardware included** — everything you need to mount the bracket is in the box
- **No hose runs** — the CCAP connects directly — zero routing, zero clamp points
- **Flush to the cab** — nothing sticking out to catch on something or get knocked loose
- **Exact fit, no guessing** — machined for the WA475-10 and WA485-10 — holes line up first try
- **~90 minute install** — straightforward enough that you won't need to clear your schedule
- **Made in the USA** — same build quality as every other EcoPro product in your yard

PRODUCT SPECIFICATIONS

Mount Type: **Side-mount, flush**

Compatible: **Komatsu WA475-10**
Komatsu WA485-10
Komatsu WA475-11
Komatsu WA485-11

Hose Required: **No**

Finish: **Powder-coat, matte black**

Made In: **USA**

PART NUMBER	DESCRIPTION
MC47510	CCAP Side-Mount Bracket — Komatsu WA475-10 / WA485-10
MC47511	CCAP Side-Mount Bracket — Komatsu WA475-11 / WA485-11

Ready to get it on the machine? Call 855-ECO-PRO2 · ecoprousa.com

©2026 EcoProUSA.com | All rights reserved. SS26-010

2443 W 12th Street, Suite 6, Tempe, AZ 85281 customerservice@ecoprousa.com (602) 820-5143